



PRODUCT BULLETIN

HINGE FOR TIMBER WINDOWS

GU Contura Window Hinge

Contura is an ideal hinge system for side hung timber windows with a 12mm rebate clearance (air gap) and with sashes weighing up to 130Kg.

Like a friction stay, the hinge is concealed within the rebate so is suitable for outward, as well as inward opening side hung windows. Unlike a friction stay, there is no movement towards the frame/transom upon initial opening and, as the sash does not encroach into the window aperture as it opens, a full, unobstructed opening such as that on a traditional casement window is achieved.

Child restrictors and friction brake stays can be fitted to side hung windows as desired.

Contura is installer-friendly with +/-2.5mm height, +/-2mm lateral and +/-1mm compression adjustment possibilities.

A simple swivel arm on the top hinge allows the sash to be quickly and easily hung or removed if necessary.

VBH codes and an example order are listed overleaf.

Key Benefits

- 130Kg sash weight
- Concealed hinge
- Unobstructed opening
- Ample 3D adjustment
- Easy sash hanging procedure
- Sash Rebate Width 280-1600mm*
- Sash Rebate Height 480-2450mm*

*Depending on perimeter locking gear used.

VBH (GB) Ltd
 VBH House, Bailey Drive
 Gillingham Business Park,
 Gillingham, Kent
 ME8 0WG
 Tel: 01634 263263
 Fax: 01634 263504
 Email: sales@vbhgb.com
 Online: www.vbhgb.com



Simply everything.

Everything simple.

GU Contura Hinge

Description	VBH Code	Box Qty
LH Top Corner Bearing	5GTT6661	100
RH Top Corner Bearing	5GTT6662	100
LH Top Corner Hinge	5GTT6663	100
RH Top Corner Hinge	5GTT6664	100
LH Bottom Corner Bearing	5GTT6667	100
RH Bottom Corner Bearing	5GTT6668	100
LH Bottom Corner Hinge	5GTT6665	100
RH Bottom Corner Hinge	5GTT6666	100

Important Note Re: Handing

Most UK windows are outward opening, where the hinges are generally viewed for handing from outside. Therefore, viewed from outside the building, an outward opening window hung on the left requires LH fittings.

However, the handings listed by GU assume an inward opening window, as is popular in their German home market, and are handed from inside.

Therefore, if an inward opening window is hinged on the right viewed from inside, RH parts are required.

In short, if your window is OUTWARD opening view from OUTSIDE, but if it is INWARD opening view from INSIDE.

Example Order 1:

Outward opening window hinged on the left viewed outside

Description	VBH Code	Qty Req
LH Top Corner Bearing	5GTT6661	1
LH Top Corner Hinge	5GTT6663	1
LH Bottom Corner Bearing	5GTT6667	1
LH Bottom Corner Hinge	5GTT6665	1

Example Order 2:

Inward opening window hinged on the right viewed inside

Description	VBH Code	Qty Req
RH Top Corner Bearing	5GTT6662	1
RH Top Corner Hinge	5GTT6664	1
RH Bottom Corner Bearing	5GTT6668	1
RH Bottom Corner Hinge	5GTT6666	1